## **Eutectic plates MAILLON**





The eutectic plates are accumulators of thermal energy that they release during transport, allowing to prolong the times of maintenance of the temperature of perishable products.

The technology and the **exclusive MELFORM design** guarantee a **robust**, **manageable** and **eco-friendly** product, thanks to the non-toxic internal liquid and the completely recyclable outer shell.

- Particularly suitable in case the containers are not used to full load.
- They do not require electrical power for their operation.
- Thanks to the excellent eutectic properties, they maintain for a long time perishable products to the optimum storage temperature.
- Guaranteed for use from -30° to +85°C.
- They ensure proper temperature retention, limiting the risk of bacterial proliferation and preserving the quality of foods and their organoleptic properties.
- The eutectic content inside of the plates is **non-toxic**: maximum safety even in case of accidental contact with the food..
- Equipped with comfortable grip handles.
- Fully recyclable at the end of operating life.

## MANUFACTURING MATERIALS Polyethylene outer shell Eutectic mixture inner content

TECHNICAL CHARACTERISTICS											
	CHILLED +3°C 180 WH	EXTRA CHILLED -12°C 155 WH	FROZEN -21°C 60 WH	EXTRA FROZEN -21°C 135 WH							
MAILLON	. 5%2	53	- 2%2 -								
TECHNICAL SPECIFICATIONS											
	0		39 02								

## Easy to use:

- the chilled plate is to be frozen to -10°C;
- the extra chilled plate is to be frozen to -20°C;
- the frozen / extra-frozen plate is to be frozen to -30°C.

Model	Code	Colour	External dim. (mm)	Eutectic temperature	Thermal energy	Weight (Kg)
					(Wh)	
Chilled plate	PEML0001	pink	360x270xh39	+3°C	180	2,9
<b>Extra chilled</b> plate	PEML9001	white	360x270xh39	-12°C	155	2,9
<b>Frozen</b> plate	PEML0002	blue	360x270xh39	-21°C	60	2,9
<b>Extra frozen</b> plate	PEML9008	green	360x270xh39	-21°C	135	2,9



Via Savigliano 34 - 12030 Monasterolo di Savigliano (CN) Tel. +39 0172812600 - Fax +39 017285991 - info@melform.com <u>www.melform.com</u>